
CHEVY II

1965 OWNERS GUIDE



A WORD FROM CHEVROLET

This Owners Guide contains important information regarding the operation and maintenance of your Chevy II.

In order to obtain maximum enjoyment and usage from your car, we suggest that you familiarize yourself with the contents of this booklet and follow the recommendations outlined.

Your Chevrolet dealer has the trained personnel and specialized equipment to properly service your Chevy II. Have him inspect your car and perform any maintenance adjustments required.

We would like to take this opportunity to thank you for choosing a Chevrolet product—and assure you of our continuing interest in your motoring pleasure and satisfaction.

CHEVROLET MOTOR DIVISION

•

GENERAL MOTORS CORPORATION
DETROIT, MICHIGAN 48202

CHEVROLET OWNER PROTECTION PLAN

The Chevrolet Motor Division considers it a most important obligation to offer each owner a recommended maintenance service guide which will relieve him of any anxiety and insure that his vehicle is regularly inspected and maintained.

Your Chevrolet dealer has presented you with a Chevrolet Owner Protection Plan Booklet. The recommended Maintenance and Lubrication Service items in this Booklet have been worked out by Chevrolet service personnel and cover items which are the owners responsibility to have checked, inspected, adjusted and lubricated at recommended time or mileage intervals.

If the services are carried out at the prescribed time or mileage intervals, wear and owner expense will be kept to a minimum. Additional services may become necessary as mileage accrues, however, the regular visit that you make to your Chevrolet dealer in following this Plan will point out desirable services as they become necessary.

In the event warranty repair is required on your Chevrolet, the Chevrolet Protect-O-Plate affixed to the back cover of your Protection Plan Booklet will assist in identifying you and your Chevrolet to your Chevrolet dealer.

TABLE OF CONTENTS

	Page		Page		Page
OWNER PROTECTION PLAN	2	CONTROLS		Electrically Operated Tail Gate Window	24
TRAILERS AND THEIR EFFECT ON CAR OPERATION	4	Light Switch	13	Operating the Folding Seats	25
OPERATING INSTRUCTIONS		Headlight Beam Switch	14	Two Seat Style Rear Seat	25
Breaking-in Period	5	Turn Signal	14	Spare Tire and Jack Stowage	26
Driving for Economy	5	Brakes	15	Super-Lift Air Adjustable Shock Absorbers	26
Starting the Engine	6	Self Adjusting	15	CLEANING HINTS	
Ignition Switch	6	Power Brakes	15	Exterior Appearance	27
Starting	6	Parking Brakes	15	Washing Your Car	27
Warm-Up	7	Clutch Adjustment	15	Polishing Your Car	27
Driving with the Synchromesh Transmissions	7	Windshield Wipers and Washers	16	Protection of Exterior Bright Metal Parts	28
Driving with the Powerglide Automatic Transmission	8	Wipers	16	Cleaning White Sidewall Tires	28
INSTRUMENTS		Washers	16	Interior Appearance	28
Generator Indicator	10	Radios	17	Dust and Dirt	28
Oil Pressure Indicator	10	Power Steering	18	Spots and Stain	28
Speedometer	11	Positraction Rear Axle	18	MAINTENANCE AND LUBRICATION	
Fuel Gauge	11	Heater	18	Gasoline and Engine Oil	29
Temperature Indicator	11	Air Conditioning	19	Gasoline	29
Brake Indicator	11	OTHER FEATURES-		Operation in Foreign Countries	29
Headlight Beam Indicator	11	Seat Adjustment	20	Engine Lubrication	30
SUPER SPORT MODEL GAUGES		Seat Belts	20	Oil Viscosity Number	30
Ammeter	11	Keys and Locks	21	Checking Oil Level	30
Oil Pressure Gauge	12	Ash Tray and Cigarette Lighter	22	Cooling System Care	30
Engine Temperature Gauge	12	Glove Box	22	Changing Tires	32
Clock	12	Air Vents	22	Tire Care	33
Tachometer	12	Hood Release	23	Tire Inflation Pressures	33
		Gas Cap	23	For Maximum Tire Life	33
		Rear Compartment	23	Periodic Maintenance and Lubrication	34
		STATION WAGON		SPECIFICATIONS	38
		Lowering the Tailgate	24	MINOR TROUBLE SHOOTING GUIDE	41
		Manually Operated Tail Gate Window	24	TROUBLE SHOOTING PROCEDURES	42

All information contained in this booklet is the latest product information available at the time of printing. The right is reserved to make changes at any time without notice.

TRAILERS AND THEIR EFFECT ON CAR OPERATION

Chevy II passenger cars are designed primarily for passenger conveyance. However, it is well known that many owners do use their Chevy II to pull trailers, and when available trailer hauling options have been used, the owners have experienced very satisfactory service.

When a trailer is attached to a car, the car becomes not only a load-carrying vehicle, but a load-pulling vehicle. The demands of this type of operation are very different from those for which the automobile is primarily designed and may present problems, such as spring and tire loading, braking, cooling, lighting, and steering. However, careful driving practices and the use of factory-recommended options will better satisfy the requirements of trailer hauling.

If in the opinion of the manufacturer a part or component of a motor vehicle has been adversely affected

by misuse of the vehicle with trailer loads, such part or component will not be covered by the manufacturer's warranty.

The size of and equipment for trailers, including such items as hitches and safety chains, brakes, lights, power-weight ratios and over-all length, are generally subject to safety regulations in all states, and it is the responsibility of the user to make certain that he is in full compliance with the regulations of the states in which he plans to operate with a trailer and of the Interstate Commerce Commission, if applicable, before doing so. Further, when operating a car with a trailer attached, the driver must realize that the performance, steering characteristics, and braking distance of his car have been altered, and that he must exercise greater caution to safely handle his car and trailer.

BREAKING-IN PERIOD

Sound design and precision manufacturing methods will permit you to operate your new Chevy II from its very first mile without adhering to a formal "break-in" schedule. However, during the first few hundred miles of driving you can, by observing a few simple precautions, add to the future performance and economy of your car.

It is recommended that your speed during the first 500 miles be confined to a maximum of 60 M.P.H., but do not drive for extended periods at any one constant

speed, either fast or slow. During this period, avoid full throttle starts and if possible quick abrupt stops.

Gentle braking during the first few hundred miles of operation will result in longer brake life and better future performance. Avoid hard stops especially during the first 200 miles of operation since brake misuse during this period will destroy much future brake efficiency.

Always drive at a moderate speed until the engine has completely warmed up.

DRIVING FOR ECONOMY

Proper maintenance and wise operation will combine to help you achieve maximum fuel economy with your Chevy II. Your Authorized Chevrolet Dealer can properly tune and maintain your car but wise operation is your responsibility. Give the car sufficient warm-up

time, do not make full throttle starts or needless sudden stops, and drive at reasonable speeds and as steady as traffic permits to gain the benefits of all the economy built into your Chevy II.

STARTING THE ENGINE

IGNITION SWITCH



The ignition switch has four positions as shown. The key may be removed only when the switch is in the OFF position. Use the ACCESSORY position for operating the accessories when the engine is not running.

STARTING

1. **AUTOMATIC TRANSMISSION**—Place control lever in N or P position to start engine.
SYNCHROMESH TRANSMISSION — Place gearshift control lever in Neutral and depress clutch pedal to the floor.
2. (a) **COLD ENGINE** — Depress accelerator pedal to floor (if equipped with manual choke, pull choke knob all the way out while holding pedal down)

then, if temperature is above 0°F., release pedal. If temperature is below 0°F., hold pedal about half-way down.

(b) **ENGINE WARM** — Depress accelerator pedal and hold about half-way down.

3. Turn ignition switch to **START** and release as soon as engine starts. If manual choke equipped model, adjust choke position to obtain smooth engine operation. As soon as engine will run smoothly without the choke, push the choke knob fully in.
4. **"FLOODED" ENGINE**—Depress accelerator to floor and hold while cranking engine. Never "pump" accelerator.

WARM-UP

Always let the engine idle for a moment or two after starting and drive at moderate speeds for several miles, especially during cold weather, to prevent unnecessary wear to the engine, axle and transmission.

MANUAL CHOKE

The Chevy II with the Super-Thrift 4-cylinder engine

CAUTION: Carbon monoxide is a poisonous gas produced by the engine of any car. It is colorless and odorless, so you cannot detect its presence. Be safe. Never start or run engine in a closed garage, or park with windows closed and engine running.

is equipped with a manual choke. Since the choke operates to enrich the fuel mixture delivered to the carburetor, its improper use can result in excessive fuel consumption. Use the choke, as outlined under "Starting," only until the engine warms up. Then if the choke is still necessary to provide smooth engine operation your Chevrolet dealer should be called upon to perform such engine adjustments as may be necessary.

DRIVING WITH SYNCHROMESH TRANSMISSIONS

1st GEAR (LOW)—Depress clutch, shift into 1st gear, slowly release clutch pedal while pressing on accelerator. As speed increases, depress clutch pedal, release accelerator and move gearshift into 2nd gear.

2nd GEAR—Release clutch pedal and depress accelerator as above, allowing car to gain speed, then, in same manner as before, move gearshift lever into 3rd gear.

3rd GEAR (HIGH)—Slowly release clutch pedal and depress accelerator pedal. This is the cruising gear for all normal driving.

TO STOP—Release the accelerator and depress the brake pedal. As car slows down, depress the clutch pedal and move the gearshift lever into Neutral.

NEUTRAL—For use when starting or idling engine.

REVERSE—Operate as for 1st Gear but always at a slow speed.

FOUR SPEED TRANSMISSION — has the shift lever extending from the floor and has its special shift pattern diagram on the trim plate as shown in the illustration.

The shift linkage may be adjusted to allow "short stroke" shift lever operation. See your Chevrolet Dealer. To shift into reverse lift up on the finger bracket just below the shift lever knob.

PUSHING TO START

- Turn key to ON position and depress clutch pedal.
- Place gearshift lever in Neutral position until car speed reaches 15 MPH.
- Move shift lever to 3rd position and slowly release clutch pedal.



DRIVING WITH THE POWERGLIDE AUTOMATIC TRANSMISSION

The Powerglide transmission is a completely automatic transmission which replaces the standard clutch and transmission. After starting the engine with the selector lever in N (Neutral) or P (Park) position, select the range desired and depress the accelerator. The transmission will do the rest. A gradual start with a steady increase of pressure on the accelerator pedal will enable the transmission to shift into the more economical cruising gear in the shortest possible time. Hard acceleration for fast starts will cause the transmission to remain in low gear for a considerably longer period with resultant higher fuel consumption. On the Super-Sport model the Powerglide shift lever is floor mounted as shown at the right. The lever may be shifted freely from N (Neutral) to D (Drive). Press lightly on the shift lever button (located on top of the shift handle) with the palm of your hand as you shift into or out of L (Low) or R (Reverse). Force this button fully down when shifting to and from P (Park).



OPERATING YOUR AUTOMATIC TRANSMISSION



P—PARK	Use only when car is stopped.	CAR PARKED
—*LIFT—		
R—REVERSE	For backing car—from stop.	NORMAL DRIVING RANGE
—*LIFT—		
N—NEUTRAL	For standing (Brakes Applied).	
D—DRIVE	For Forward Driving. Step hard on accelerator for extra acceleration below 40 mph	
—*LIFT—		SAND, SNOW, MUD AND STEEP GRADES
L—LOW (Powerglide)	For hard pulling at low speeds and climbing or descending steep grades. Shift to L only below 40 mph.	

*Lifting clears stops that prevent unintentional shifts to Reverse, Park or Low.

ROCKING CAR

"ROCK" car to escape from mud, sand or snow, by holding down the accelerator a small amount and moving the selector lever between "D" and "R". With a little practice the selector lever movements may be coordinated with the forward and backward motion of the car.

PUSHING TO START

- Turn off all electrical loads such as headlights, radio, heater, etc., until after engine is started.
- Turn key to ON position, place the selector lever in "N" until car reaches 25 to 30 miles per hour and move the lever to "L" position.
- When engine starts, move the selector lever to "D" and proceed in a normal manner.

NOTE: *It is best never to tow the car to start. When the engine starts, the car may accelerate into the tow car.*

TOWING

- Place selector lever in "N" and do not exceed 35 miles per hour.
- If transmission is not operating properly, tow with rear wheels raised or drive shaft disconnected.

- If towing at speeds above thirty-five miles per hour, or car must be towed for extended distances (over 50 miles) drive shaft must be disconnected.

WHEN PARKING YOUR CAR


To be double safe, always engage the parking brake (see page 14) and place the transmission selector lever in "Park" position when leaving your car unattended.

AUTOMATIC TRANSMISSION DRIVING CAUTIONS

- Do not accelerate engine in L, D, or R with the brakes engaged. This can cause damage by overheating transmission.
- DO NOT hold car on an upgrade by accelerating engine. Use brakes.
- Do not use Low position except for hard pulls at low speed or downhill braking at speeds below forty MPH.
- Do not shift into Reverse or Park before coming to a complete stop.
- Always engage parking brake when parked.

When towing any vehicle on its front wheels, the steering wheel should be secured to maintain a straight forward position.

INSTRUMENTS



Familiarize yourself with these instruments and their uses and make it a practice to scan the instrument cluster as you start the engine and periodically as you drive.

GENERATOR INDICATOR LIGHT

This indicator light provides a quick check on the generating system of your Chevy II. The red light will be on when the ignition key is in the "on" position, but before the engine is started. After the engine starts, the light should go out and remain out. If the light remains on when engine is running, have your Authorized Chevrolet Dealer check the electrical system as soon as possible.

OIL PRESSURE LIGHT

This light will be on when the ignition switch is turned on but before the engine is started. Occasionally the light may be seen to flicker momentarily, but this will do no harm. However, if the light remains on during normal driving speeds, the engine should be stopped until the cause of the trouble can be located and corrected. Driving the car with low oil pressure can cause serious engine damage.

SPEEDOMETER

The speedometer indicates the speed of the car in miles per hour. The odometer, which operates in conjunction with the speedometer, registers accumulated mileage.

FUEL GAUGE

This electrically operated gauge indicates the amount of fuel in the fuel tank. It is operative only when the ignition switch is in the "ON" position. When the ignition switch is turned "OFF" the needle will not necessarily return to the EMPTY mark but may stop at any point on the dial.

TEMPERATURE INDICATOR LIGHT

Should the temperature of the engine coolant reach the point where there is danger of engine damage, this red indicator light will come on. If this occurs, stop the

engine until the cooling system is thoroughly checked and the cause of the overheating is found and corrected. As a check on the condition of the bulb and circuit of this indicator light, it will come on when the ignition key is in "START" position but before the engine is started. The light should go out after the engine starts.

BRAKE INDICATOR LIGHT

This indicator light, when installed, will flash when the ignition key is turned "ON" if the parking brake is engaged, warning you to release the brake before proceeding. See "Parking Brake" on page 15.

HEADLIGHT BEAM INDICATOR LIGHT

This indicator light will be on whenever the high beam, or "brights," of your headlights are in use. Always "dim" your headlights when approaching cars. See "Headlight Beam Switch" on page 14.

SUPER SPORT MODEL GAUGES

AMMETER



The ammeter shows the rate at which the battery is being charged or discharged. The Delcotron charging system is equipped with a regulator which controls the charge according to battery requirements. When the Delcotron generator is supplying more than the current demand, the ammeter will show the charging rate while a discharge will be shown if the current demand is more than the Delcotron output. With the battery fully charged, the charging rate will be low, thus giving an indication of battery condition.

OIL PRESSURE GAUGE

The oil pressure gauge indicates the pressure at which oil is being delivered to the various parts of the engine requiring lubrication. Pressures registered by the gauge may vary according to outside air temperatures or weight of oil being used. Oil pressure of a cold engine being operated at a given speed will be somewhat higher than when the engine is at normal operating temperature at the same speed. Prolonged high speed operation on a hot day at the given speed will result in somewhat lower oil pressure readings.

ENGINE TEMPERATURE GAUGE

Showing engine coolant temperature, gauge readings will vary with air temperature and operating conditions. Hard driving or prolonged idling in very hot weather may produce above normal readings. The ignition switch must be on for accurate readings.



CLOCK


Reset the clock, if your car is so equipped, by pulling out the knob and turning the hands clockwise if slow, counterclockwise if fast. This will, if the clock error is three minutes or more, automatically compensate for time gain or lag. Several settings, several days apart, may be needed to properly adjust the clock mechanism. Have your clock cleaned and oiled by a competent clock service man at least every two years.

TACHOMETER

The tachometer indicates the speed of the engine in revolutions per minute. The colored area between 5000 and 5500 rpm, indicates the maximum speed which the engine should be run in any one gear position.



CONTROLS



LIGHT SWITCH

The three position light control switch controls the headlights, taillights, parking lights, instrument lights and dome lights as shown. The headlight and parking light circuits are protected by a circuit breaker in the light switch. An overload will cause the lights to "flicker" on and off. If this condition exists, have your Chevrolet Dealer check your headlight and parking light wiring immediately.

HEADLIGHT BEAM SWITCH



"High" and "low" headlight beams are controlled by the floor button at your left foot. The Headlight Beam Indicator, located below the speedometer dial, will be lighted when the high beams are in use. Always use "low beam" when approaching cars.

TURN SIGNAL

Move the lever up or down to indicate a right or a left turn respectively. As the parking lights and stoplights flash to indicate the direction of the turn, the instrument panel indicator flashes. When the turn is completed the lever will return to neutral.




Remember to turn on the signal well in advance of your turn.

LIGHTING SYSTEM TROUBLE CHECKS

- If headlights flicker on and off rapidly, your Authorized Chevrolet Dealer should be called upon immediately to correct the overload condition.
- If the tail light fuse blows out, the instrument panel lights will also be inoperative. Check both the instrument panel fuse and the tail light fuse. (See page 40.)
- If, when signalling a turn, the indicator light comes on but does not flash, a burned out front or rear turn signal lamp on that side or an improper flasher is indicated.
- If the turn indicator comes on and stays on when signalling a left or a right turn and no "clicking" is heard, replace the flasher.
- If flasher clicks but the indicator light does not operate, replace the indicator bulb.
- If, when signalling a turn, the indicator light operation is very rapid, an improper flasher is indicated.
- Series type 2-bulb flashers are standard equipment on your Chevy II. Replace with the same type.

Foot Controls



SELF ADJUSTING BRAKES

The self adjusting brakes usually adjust themselves as necessary. Should brake pedal travel become excessive, drive the car forward and backward several times applying brakes to stop the car. Pedal travel should return to normal after several reverse stops.

Power Brakes

Optional power brakes make use of engine vacuum to help you bring your car to a stop with much less braking effort than needed with regular brakes. It may be wise to make several trial stops to familiarize yourself with their easier operation.

A built-in vacuum reserve supplies one power as-

sisted stop should the engine stall, after which additional foot pressure will be needed for brake response.

Parking Brake

The hand operated parking brake is conveniently located just to the right of the steering column.

- Pull the cane type handle toward you to engage the parking brake. This mechanically sets the rear wheel brakes. The handle will remain in the extended position while the parking brakes are applied.
- To release the parking brake, turn the handle clockwise and allow it to return to its original position.

The brake indicator light, if installed, is illuminated, when the brake is applied and the ignition key is on, by a flashing red light.

CLUTCH ADJUSTMENT

Clutch adjustment should be checked and adjusted periodically as necessary to compensate for clutch facing wear. To check, depress pedal by hand until resistance is felt. Free travel of pedal should be approximately $\frac{3}{4}$ -inch; if very little or no free travel is evident, clutch adjustment is required.

WINDSHIELD WIPERS AND WASHERS

Wipers

Turn the single speed wiper control knob clockwise to start, counterclockwise to stop.

The optional two speed wiper is operated in a like manner, but has three switch positions, OFF, SLOW and FAST.



Washers

Windshield washers are optional with the single speed wiper while the optional two speed wiper is equipped with an integral washer mechanism.

Operate the washers by pressing the button in the center of the wiper control knob. This will send a measured amount of water or other cleaning agent onto the windshield and also will cause the wiper knob to turn, thus starting the wiper motor. The wiper will then continue to operate until manually turned off at the wiper knob.

Keep the water container under the hood filled at all times. Avoid operating the washer when jar is empty.

G. M. Windshield Washer Solvent added to the water aids in cutting road film and grease from the windshield and is recommended for use at all times except when the temperature falls below freezing.

NOTE: The solvent will not prevent spray from freezing on glass. Do not attempt to clean windshield in freezing weather unless the cold weather precautions described in the paragraph below are observed.

Cold Weather Washer Operation

During periods when temperatures of freezing or below can be expected, use G. M. Windshield Washer Anti-freeze and prewarm the windshield using the heater defrosters before attempting to use the washers.

Fill the washer jar only $\frac{3}{4}$ full in winter to allow expansion if the temperature should fall low enough to freeze the solution.





ANTENNA

For best FM operation the antenna must be extended to a length of 30 inches. For best AM operation the antenna should be fully extended.



CHEVY II "ALL TRANSISTOR" RADIOS

To operate the radios, the ignition switch must be in "ON" or "ACC" position.

● ● ● AM RADIOS

The left hand control knob is the "on-off" switch and volume control. At its base is the tone control wing knob. The right hand knob is the manual station selector. With the optional rear seat speaker, a wing knob at the base of the station selector knob allows use of front, rear or both speakers.

Five push buttons allow station selection in the Push Button radio. To preset, pull the push button "out" as far as it will go, tune in the desired station manually and then push the button fully "in." Repeat for each push button.

● ● ● AM/FM RADIO

This set receives clear static-free FM broadcasts as well as standard AM programs. Move the slide bar to select AM or FM reception. Controls are the same as in Manual and Push Button radios. FM broadcasts may be received as far as 60 miles from the sending station, depending on the power of the station and existing terrain. Push buttons may be set for AM, FM or both.

● ● ● STEREO MULTIPLEX ADAPTER

The Stereo Multiplex Adapter permits FM stereo reception with the AM/FM radio. Radio controls are used to turn the set on and off and for station selection. Controls on the adapter are Volume, Tone and Balance (to balance the front and rear speakers). For a pleasing stereo effect the front speaker reproduces one channel and the rear speaker reproduces the other channel. The indicator light on the adapter will be lighted when the radio is tuned to an FM stereo station. Most broadcasts on such stations will be in stereo.

POWER STEERING

The optional Power Steering supplies about 80% of the effort needed to turn the front wheels. Should the engine stop, your Chevy II may still be steered safely.

POSITRACTION REAR AXLE

The Positraction Rear Axle gives you constant driving force on both rear wheels; especially helpful in the winter and during other slippery driving conditions.

In normal use, light throttle application will supply maximum traction. When starting with one rear wheel on an excessively slippery surface, slight application of the parking brake may be necessary to gain maximum traction.

HEATER OPERATION



Pull the AIR PULL-FAN knob fully out before operating fan, then rotate the knob to obtain low, medium or high fan speed.

Pull the TEMP knob fully out to provide maximum output temperature. Push in the knob as desired to regulate temperature.

Pull the DEF knob fully out to obtain maximum defrosting. Intermediate setting may be used to divide the air flow between the defroster and the heater outlet,

HEATER OPERATING TIPS

- The Heater receives air from the inlet in front of the windshield. Always be sure the inlet is clear of snow or other restriction.
- Operate the heater for several minutes before using the defroster. This will clear the system of moisture and help prevent windshield fogging.
- Keep all windows and vents closed to reduce drafts and noise.
- If less than maximum heat is desired, operate fan on low or medium speed and control the output air temperature with the TEMP knob.
- Additional ventilation may be obtained by pulling the AIR PULL-FAN knob fully out and operating the fan.

ALL-WEATHER AIR CONDITIONING SYSTEM



The Chevy II Deluxe Air Conditioning System operates in conjunction with the heater to provide conditioned air for maximum passenger comfort during every season of the year. Air flow may be directed through the two side louvers, two ball outlets and the front louver.

OPERATION

Pull the PULL FOR AIR COND knob fully out to turn on the air conditioner.

Turn the TEMP-COOL knob to obtain the degree of cooling desired; fully clockwise gives maximum cooling.

Pull the heater AIR PULL-FAN knob fully out and rotate the knob to obtain low, medium or high speed. After the car has cooled, position the knob approximately $\frac{1}{4}$ " out.

CUSTOM AIR CONDITIONING SYSTEM



The Custom Air Conditioning System will provide you with warm weather driving comfort.

OPERATION

- Turn the FAN knob to control the three-speed blower as desired.
- The TEMP-COOL knob may be regulated to provide the degree of cooling desired. Fully clockwise provides maximum cooling.

AIR CONDITIONING OPERATING TIPS

- Close all windows and vents when operating the system except when the car interior is very hot.
- When operating the air conditioner at altitudes over 4000 feet, reduce the cooling output slightly to avoid evaporator freeze-up.
- For operation during marginal weather, move the PULL FOR AIR CONDITIONING knob partially out to divide air flow between the heater and air conditioner outlets. Adjust the heater TEMP knob and the AIR CONDITIONER TEMP-COOL knob to provide desired heat at floor level and cooled air at breathing level.

FRONT SEAT ADJUSTMENT



The front seat may be quickly and easily adjusted forward or rearward to provide maximum driving comfort. (Your Authorized Chevrolet Dealer can make additional adjustments to further tailor the seat to your particular comfort requirements.)

Pull back the seat adjuster lever, located on outboard side of the front seat, to unlock the seat and allow adjustment to the front or rear. As the seat slides forward, it tilts also to provide best posture and increased driving ease. Release the lever to lock the seat in the desired position.

SEAT BELTS


Fasten your seat belt by pushing the metal catch into the buckle until it "snaps" into place. Tighten the belt until comfortably snug by pulling on the loose end extending from the buckle. Do not wear belt loosely. Loosen by turning the entire buckle outward. Lift up the buckle lever to unlatch and release the belt. *Never buckle an individual seat belt around more than one person.*

It is recommended that seat belt retractors be used on the outboard belt half only. When buckling the belt be sure it is fully extended so there is no webbing wound around the retractor drum, then adjust for proper fit at the buckle.

Clean belts when necessary, without removing from the car, with a stiff bristle brush using a detergent recommended for nylon. *Never bleach or dye seat belts.*



KEYS, DOORS AND LOCKS



The octagonal-end key operates the ignition switch and the front doors of your Chevy II.

The round-end key operates the glove box, trunk.

Each key has a serial number stamped on a removable plug. This number will enable you to have another key made in the event that the original is lost.

To avoid the possibility that unauthorized persons might duplicate your key, it is strongly recommended that you record the serial number and then, with a hammer and punch, remove the knockout plug.

Door Locks

Chevy II door locks are designed both for passenger safety and for the security of your car and possessions. Always keep the doors locked when driving as well as when leaving the car unattended.



Locking the Doors

FRONT DOORS: *Inside*—push inside release handles fully forward. *Outside*—use ignition key.

REAR DOORS: *Inside*—push down on locking button. (Rear doors can be locked from the inside only.)

Unlocking the Doors

FRONT DOORS: *Inside*—pull inside release handles fully rearward. *Outside*—use ignition key.

REAR DOORS: *Inside*—lift up on locking button. (Rear doors must be unlocked from inside.)

The rear door release handles are inoperative whenever the locking button is depressed. This feature is of particular value if young children ride in the back seat. Before the rear door can be opened from either inside or outside, the locking button must be raised.

ASH TRAY AND CIGARETTE LIGHTER

Pull the "drawer" out to expose the ash tray. To empty the tray, pull out to the stop, depress the tray, and remove from the instrument panel. The entire ash tray and lid assembly is thus removed. When cleaned, slide back into place. On cars so equipped, push in on the cigarette lighter to operate. When heated ready for use, it will "snap" back into normal position.



GLOVE BOX

The glove box is locked and unlocked with the round-end key. When open, the door forms a small table for cups or glasses.



AIR VENTS



The air vents in each kick panel admit air from the vent grille just ahead of the windshield. Control knobs open and close the vents.


HOOD RELEASE

Pull the hood release to open the counterbalanced hood. If the hood must be slammed to insure closing, it is in need of adjustment. A hard slam should not be necessary.



GAS CAP


The gas cap is located in the left rear fender in all models of the Chevy II passenger cars and station wagons. Turn the cap to the left to open and to the right to close. When closed the cap fits flush with the fender. The cap is not vented.



REAR COMPARTMENT

Unlock and open the counterbalanced trunk lid with the round-end key. Close the lid firmly to close the lock. The spare tire and auto jack are located in the trunk as shown. The illustration below illustrates proper jack and tire stowage.

See Maintenance and Lubrication section for tire rotation intervals and inflation pressure recommendations.



STATION WAGONS

LOWERING THE TAILGATE

Before opening the tailgate, whether your station wagon is fitted with an electrically operated or a manual tailgate, always lower the tailgate window fully.

Cowl vents should be open to prevent dust or

obnoxious fumes from entering the vehicle through the tailgate opening.

Tailgates which have an electrically operated rear window incorporate a safety feature which prevents raising the tailgate window until the tailgate is fully closed.

Manually Operated Tailgate Window

To open:

- Unlock the window winding lever, if necessary, by means of the round end key.
- Pull the crank knob out.
- Turn the window fully DOWN and snap the knob back into the stowed position.
- Push the release lever located at the top center of the inner face of the tailgate to the LEFT and lower tailgate.



To Close:

- Lift the tailgate and slam to close.
- Roll up the tailgate window if desired.
- Winding lever may be locked if desired.

Electrically Operated Tailgate Window

The electrically operated tailgate window (optional equipment) may be opened by means of two switches:

1. A key operated switch on the tailgate.
2. A switch on the instrument panel.



OPERATING THE FOLDING SEATS

The rear seats of your Chevy II Station Wagon may be quickly and easily converted into cargo space where needed.


TWO SEAT STYLE REAR SEAT

To Lower Seat

- Release the locking lever on the right hand side of the rear seatback.
- Pull seatback forward and down.


To Raise Seat

- Lean on the front edge of the seatback panel to remove tension from the filler panel.
- Lift up the filler panel at the location shown above.
- Then, lift seatback up and rearward until it locks into place.



SPARE TIRE AND JACK STOWAGE

The spare tire and jacking equipment are stowed behind in the right rear quarter panel. The tire is covered by a plastic boot. The boot should be removed and installed while the wheel and tire are out of the vehicle. A movable flap allows access to the large wing nut which secures the tire and jacking equipment. Be sure the jacking equipment is properly installed before the tire is set into place to avoid annoying rattles.



STATION WAGON

SUPER-LIFT AIR ADJUSTABLE SHOCK ABSORBERS

Optional Super-Lift air adjustable shock absorbers allow you to ride with the trunk or load space of your car or station wagon fully loaded but with no annoying sag or bumps. Air is added to the rear shocks as needed through the air valve located along side the gas filler

neck.

A minimum pressure of 10 psi. should be maintained at all times. After the car is loaded, pressure may be increased until the rear of the vehicle reaches the desired riding height or to a maximum of 90 psi.

EXTERIOR APPEARANCE

Your Chevy II is finished with General Motors "Magic-Mirror" acrylic lacquer. This is a finish of maximum beauty which, in depth of color, gloss, retention and durability is superior to conventional finishes.

Washing Your Car

The best way to preserve the finish is to keep it clean. Normally only frequent washings are required to maintain its original beauty. Wash the car in either warm or cold (never hot) water, not in the direct rays of the sun, and not while the sheet metal surfaces are hot. Never wipe dirt from dry painted surfaces because this may scratch the finish. The use of strong soaps and chemical detergents should be avoided and in any event cleaning agents should be promptly flushed from the surface and not allowed to dry or they may streak the finish.

Polishing and Waxing Your Car

Even though the acrylic paint on your car is more durable than conventional finishes, under certain conditions you may wish to wax or polish your car to provide maximum protection. Calcium chloride and other salts, road oil and tar, tree sap, chemicals from factory chimneys and other foreign matter may damage any known automobile finish if allowed to remain in contact with

the paint film. Prompt washing may not thoroughly remove these deposits and, particularly in geographical areas where these exposure conditions are severe, properly applied polishes and waxes of known quality will provide the best protection. Many Chevrolet Dealers offer various types of polishes or waxes which have proven of real value in maintaining a good paint finish.

NOTE: Some chemical cleaners used for removing road oil and tars from painted surfaces have been found to be detrimental to acrylic finishes. When purchasing a cleaner, make sure that the instructions specifically state that the contents can be safely used on an acrylic finish.

BRIGHT METAL TRIM LOCATION AND TYPE

ALUMINUM	Body side and Rocker Sill Mouldings Headlight, Tail light and Parking Light Frames Radiator Grille Back-up Light Frames
CHROME	Bumpers Hood Emblem Door Handles and Key Locks Series Nameplates and Ornaments Ventipane Channel Side Window Glass Mouldings Deck Lid or Tailgate Emblem and Control Hub Caps
STAINLESS STEEL	All bright metal trim not listed above may be assumed to be Stainless Steel.

Protection of Exterior Bright Metal Parts

All bright metal parts of the car should be regularly cleaned and protected against the same substances harmful to the painted surfaces. Normally, washing with water is all that is required. However, G. M. Chrome Polish may be used on CHROME or STAINLESS STEEL trim if necessary. Use special care with ALUMINUM trim. Never use auto or chrome polish, steam or any caustic soap to clean aluminum. Wash only with luke-warm water, and if necessary, a mild soap. Rinse well and dry thoroughly. In severe cases, road oil and tar may be removed from aluminum trim by cleaners specified as safe for use on acrylic finishes.

It is recommended that all bright metal parts of your Chevy II, after being thoroughly cleaned, be given a coating of wax and rubbed to a high polish. This will serve to keep corrosive agents away from these surfaces, and should be repeated as often as required.

Cleaning White Sidewall Tires

Use soap, warm water or a tire cleaner and a stiff brush to remove road grime and dirt from white sidewall tires. A fine grade of steel wool will remove severe curb scrapes. Do not use gasoline, kerosene or any oil product which could discolor or deteriorate the rubber.

CAUTION: Some white sidewall cleaners will cause serious damage to aluminum trim. Use caution when cleaning tires with this type of cleaner that none is splashed or sprayed on aluminum trim.

INTERIOR APPEARANCE

Dust and Dirt—Clean the interior of your car frequently, using a broom or vacuum cleaner. A damp cloth will wipe dust from hard surfaces.

Spots and Stain—Remove upholstery stains as soon as possible or they may become "set" and difficult or impossible to remove. First determine the type and age of the stain and the kind of upholstery material. Kar Kleen Upholstery Cleaner or Kar Kleen Upholstery Spot Cleaner, available from your Authorized Chevrolet Dealer, will remove most stains. For oil, grease and road grime stains not removed by these cleaners the use of a volatile type cleaner is recommended. Do not use alkaline cleaners for they may damage the color or finish of the materials. Other solutions such as hot or cold water, ammonia water, soap, ink eradicator, etc., will probably discolor and disturb the material.

GASOLINE AND ENGINE OIL

In the selection of gasoline and engine oil to be used, it is best to consider the reputation of the refiner or marketer. This is the best means of obtaining gasoline and oil of high quality.

GASOLINE

The 4- and 6-cylinder engines and V-8 engines with two-barrel carburetors are designed to operate efficiently on regular grade gasolines commonly sold in the United States and Canada.

The higher performance V-8 engines are designed to operate efficiently on premium grade gasolines commonly sold in the United States and Canada. Use of regular grade gasolines in these higher performance V-8 engines may result in excessive knocking.

Since the octane quality of all regular grade or of all premium grade gasolines is not the same and factors such as altitude, terrain and air temperature affect operating efficiency, excessive knocking may result, even though you are using the grade of gasoline recommended for your engine. If excessive knocking occurs in your engine, it may be necessary to use the next higher grade of gasoline, and if knocking continues, consult your Authorized Chevrolet Dealer.

If you plan to operate your Chevy II outside the continental limits of the United States or Canada, there is a possibility that the best fuels available are so low in octane quality that excessive knocking and serious engine trouble may result from their use. To minimize that possibility, write to Chevrolet Motor Division, General Motors Corporation, Service Operations Department, Detroit, Michigan 48202 giving: Your engine serial number (see page 38), the compression ratio of your engine (see page 39) and the country or countries in which you plan to travel. You will be furnished details of adjustments or modifications which should be made to your engine by your Chevrolet dealer prior to your departure. After arriving in a foreign country, contact the nearest authorized General Motors dealer for brand names of the best fuels available and advice as to where they may be purchased.

In all cases excessive knocking should be avoided as much as possible in order to prevent possible engine damage. Operation of your car under conditions of continuous or excessive knocking constitutes misuse of the engine for which the Chevrolet Division is not responsible under the terms of the manufacturer's New Vehicle Warranty.

OIL VISCOSITY AND QUALITY

		Recom- mended SAE Viscosity Oil	Recom- mended SAE Multi- Viscosity Oil
Lowest Anticipated Temperature During Time Oil Will be in the crankcase	32° F.	SAE 20 or 20W	SAE 10W-30
	0° F.	SAE 10W	SAE 10W-30
	Below 0° F.	SAE 5W	SAE 5W-20

NOTE 1: SAE 30 or 10W-30 is recommended when most of the driving is at high speeds and/or at temperatures above 90° F.

NOTE 2: SAE 5W-30 oils may be used during periods when temperatures of 32° and below are to be expected.

The use of high quality oil of correct viscosity is your best assurance of continued reliability and performance from your engine. It is recommended that you use an oil which, according to the label on the can, is (1) intended for Service "MS" and (2) passes car makers' tests or meets General Motors Standard GM 4745-M.

To flush the crankcase, drain and refill with SAE 10W oil, run engine at fast idle until hot, then drain immediately and refill with recommended grade of oil.

CHECKING OIL LEVEL

Regardless of the change interval being followed check the oil level (with engine hot) on the dipstick regu-

larly. Keep oil level between the FULL and ADD marks, by adding oil when level is at or below ADD mark. It is not necessary to keep the level at the FULL mark. Capacity of the various engines will be found on Page 38.

The four-cylinder and six-cylinder crankcase dipsticks are located on the right side of the engine as shown in the four-cylinder engine illustration shown here. The V-8 dipstick is located on the left side of the engine.



COOLING SYSTEM CARE

Your Chevy II engine cooling system is equipped with a 180° thermostat and is designed to operate on permanent type (ethylene glycol) anti-freeze. Non-Permanent type coolants are not recommended since they are not satisfactory for year around use and may not effectively inhibit corrosion of the engine cooling

system when used with the quality of water found in some areas.

If the anti-freeze was installed at the factory or if it meets the requirements of General Motors Standard GM 1899-M which contains adequate corrosion protection, it may be left in the cooling system for 24 months or 24,000 miles whichever occurs first.

Check the coolant level regularly. Level should be 1" below top of filler neck when cold. Add water or permanent anti-freeze as required to maintain proper level. Concentration of coolant should be to 0°F. or below to insure sufficient corrosion protection.

Drain and flush cooling system every 24 months. Fill with mixture of permanent type anti-freeze (GM 1899-M or equivalent) and water to provide proper concentration of coolant.

Each fall have your Chevrolet dealer inspect the cooling system to insure that all connections are leak-proof and anti-freeze content will provide adequate protection in cold weather.

The standard radiator cap is a 13 lb. pressure type. Air conditioned vehicles are equipped with a 15 lb. pressure type cap to provide added protection.

Pressure Type Radiator Cap



To remove the cap: Turn a quarter of a turn to allow the pressure in the cooling system to escape safely, then remove the cap. Always be sure that radiator cap is installed tightly.

CAUTION: After a long, hard drive, or after driving during hot weather, never attempt to remove the radiator cap until the engine has been stopped and allowed to cool for several minutes. Then, carefully remove the cap as described above.

Draining the Cooling System

To Completely drain the cooling system:

- Open the drain cock at the center bottom of the radiator. This will drain the radiator and hoses but will not allow the coolant to drain from the engine block.
- Remove the drain plug located at the rear side of the block to complete the draining procedure.




Be sure to close the radiator drain cock and replace the engine drain plugs before refilling the cooling system.



CHANGING TIRES

Remove jack and spare tire from rear compartment and position jack under bumper as shown on instruction



sticker located in the spare tire storage area. The jack load rest must locate under the bumper as shown.

Set parking brake, block diagonally opposite wheel, remove hub cap and loosen wheel nuts. Set small lever on jack to UP position, and using wheel nut wrench as a jack handle, raise car until the tire clears the ground. Remove the wheel and put on the spare, tightening the wheel nuts. Move the jack control lever to down position and lower car one notch at a time until wheel touches ground. Retighten wheel nuts and replace hub caps.

TIRE CARE

Keep your tires inflated to the recommended pressures. Over-inflation can adversely affect riding comfort, quietness and tire life while under-inflation affects vehicle handling and tire life.

Vehicle Loading and Tire Selection

Full load capacity of the vehicle is:

All Models except Station Wagons	1100 lbs. Total:	3 Passengers in Front Seat
		3 Passengers in Rear Seat
		200 lbs. Luggage
2 Seat Station Wagons	1200 lbs. Total:	3 Passengers in Front Seat
		3 Passengers in Rear Seat
		300 lbs. Luggage

Manufacturer's original equipment 4-ply rating tires are designed and thoroughly tested to meet all normal requirements of your vehicle as outlined above.

RECOMMENDED TIRE INFLATION PRESSURES	Tire Ply Rating	Average Owner Service Up to 5-Passenger Load (Normal Inflation)				Continuous Service with Over 5-Passenger Load Up to Full Load Capacity (Maximum Inflation)			
		Cold*		Hot**		Cold*		Hot**	
		Front	Rear	Front	Rear	Front	Rear	Front	Rear
All Except Station Wagons	4	24	24	29	29	@24	30	@29	35
Station Wagons	4	24	28	29	33	@24	30	@29	35


*After car has been parked for 3 hours or more, or driven less than one mile.

**Pressures can rise as much as 7 pounds above cold figures depending on loads carried, length of driving, and car speed prior to checks.

@Front tire loads do not increase appreciably with passenger or cargo loading, therefore, the above is recommended for best steering characteristics.

For continuous full load service or heavy duty operation, eight ply rated or oversized tire options are recommended at the above recommended tire pressures. Their use is particularly applicable to Station Wagons.

FOR MAXIMUM TIRE LIFE • Keep tires properly inflated. • Check regularly for cuts, bruises and puncturing objects. Do not remove a puncturing object until prepared to change or repair the tire. • Avoid sudden starts and stops; take curves and corners at a reasonable speed. • Avoid driving over curbs, sharp objects or chuckholes. • Have wheel alignment checked periodically, especially when tires show unusual wear. • Rotate the tires every 6,000 miles as shown.



PERIODIC MAINTENANCE AND LUBRICATION RECOMMENDATIONS

FRONT SUSPENSION

Every 6,000 miles or 6 months whichever occurs first—Lubricate fittings with water resistant EP Lubricant.

Ball joints should not be lubricated unless their temperature is 10° F. or higher. During colder weather, they should be allowed to warm up as necessary before lubrication.



STEERING LINKAGE

Every 6,000 miles or 6 months—Lubricate fittings with water resistant EP Lubricant.

CLUTCH CROSS-SHAFT LEVER

At 36,000 miles, if necessary, remove plastic plug and install a lubrication fitting and lubricate with water resistant EP Lubricant.

STEERING GEAR

Every 36,000 miles—check steering gear lubricant level in the following manner:

1. Remove the forward and the outboard steering gear cover attaching screws.
2. Inject water resistant EP Lubricant into the forward cover attaching screw hole until lubricant begins to come out of the outboard screw hole.
3. Replace both cover attaching screws.

POWER STEERING PUMP RESERVOIR

Every 6,000 miles or 6 months—Check level in pump reservoir. Fill as required with automatic transmission fluid "Type A" with AQ-ATF-A mark. Check oil level and fill pump with oil hot and wheels in straight ahead position only.

FAN BELT

Every 6,000 miles inspect fan belt for wear, fraying, cracking and tension. Belt should be retightened only when it deflects more than $\frac{1}{2}$ " with moderate thumb pressure applied midway between pulleys.

DISTRIBUTOR CAM LUBRICATOR

4 and 6-Cylinder Engine

Rotate cam lubricator 180° at 12,000 mile intervals—replace at 24,000 mile intervals.

8-Cylinder Engine

Change cam lubricator end for end at 12,000 mile intervals. Replace at 24,000 mile intervals.

AIR CLEANER*

Polyurethane Type

Every 12,000 miles—Clean element in suitable solvent such as kerosene, squeeze out all solvent, then soak in engine oil and squeeze out. Wrap in clean, dry cloth to squeeze out excess oil.

Paper Element Type

First 12,000 miles inspect or test element; if satisfactory, re-use element but recheck every 6,000 miles until replaced. Element must not be washed, oiled, tapped, or cleaned with an air hose.

Flame Arrestor

Every 12,000 miles—Clean the arrestor (located in the base of the air cleaner) with kerosene or a suitable solvent. Dry with compressed air.

ENGINE OIL CHANGE*

Engine oil should be changed at 60 day or 6,000 mile intervals, whichever comes first.

Crankcase Breather Cap

At every oil change—Clean in solvent and reoil.

FUEL FILTER

Replace filter element, located in carburetor inlet, if carburetor flooding occurs.

OIL FILTER*

6,000 miles or every six months, whichever comes first—Change filter element.

CRANKCASE VENTILATION

Valve Type*

At every oil change the valve should be tested for proper function and replaced when necessary.

Fixed Orifice Type*

Check every 6,000 miles or at every oil change. If dirty or plugged clear with suitable size drill. Twist drill by hand to remove any sludge or carbon formation.

*Under prolonged dusty driving conditions, it is recommended that these operations be performed more often.

TRANSMISSION

3-Speed and 4-Speed

Every 6,000 miles—Check at operating temperature and fill as necessary to level of filler plug hole with lubricant specified in Note 2, page 37.

Powerglide

Every 6000 miles—Check fluid level on dipstick with engine idling, selector lever in neutral position, parking brake set and transmission at operating temperature. If fluid level is below full mark on dipstick, add small amount of Automatic Transmission Fluid Type "A" bearing the mark AQ-ATF followed by a number and the suffix letter "A". Recheck fluid level on dipstick and again add a small amount of fluid if needed to bring level to full mark. **DO NOT OVERFILL.**

Lubricate Powerglide shift linkage at frame and transmission with lubricant specified in Note 1, page 37.

Every 12,000 miles (more frequently*, depending on severity of service, if vehicle is used to pull trailers, carry full loads during high ambient temperatures, operate in mountainous terrain or operate under other severe conditions)—Remove fluid from the transmission sump and add one and a half quarts* of fresh fluid. Operate transmission through all ranges and check fluid level as described above.

REAR AXLE

Standard Rear Axle

Every 6,000 miles—Check and keep filled to level of the filler plug with lubricant specified in Note 2, page 37.

Positraction Rear Axle

Same as the standard rear axle but use only the special Positraction Rear Axle Lubricant available from your Chevrolet dealer.

FRONT WHEEL BEARINGS

Whenever front brakes are serviced—Clean and re-pack bearings with high melting point wheel bearing lubricant.

BATTERY

Check fluid level—keep filled with distilled water to bottom of the split ring in the vent tube. **DO NOT OVERFILL.**

Every 6,000 miles—Clean and oil battery terminals and oil felt washer with engine oil.

Check state of charge regularly especially in freezing weather, when an undercharged battery may freeze and break. Clean top of the battery regularly with dilute ammonia or soda solution and flush with clean water.

*Except if vehicle is equipped with transmission provided in heavy duty service options. If so equipped, drain converter and sump every 12,000 miles and add approximately seven and a half (7.5) quarts of fresh fluid.

PARKING BRAKE

Every 6,000 miles — Apply lubricant specified in Note 1, page 37 to pulley bearing area, parking brake cable, cable guides and at all operating links and levers.

BRAKES

Lining

Have brake linings inspected periodically. Frequency of inspection will depend on traffic, terrain and the driving habits of the driver.

Main Cylinder

Every 6,000 miles—Check fluid level and maintain $\frac{1}{4}$ " below filler opening with G. M. Hydraulic Brake Fluid, Super No. 11.

AIR CONDITIONING

After the first 6,000 miles—have your Chevrolet Dealer check the tightness of all hose clamp connections.

Every 6,000 miles—Check sight glass under the hood, after the system has been in operation for several minutes. Sight glass should be clear. Bubbles

or dirt visible at all times indicate a leak which should be repaired immediately by your Chevrolet dealer.

Every Week—during winter months—run the system for 5 minutes to insure proper lubrication of the seals and moving parts.

HEADLAMP AIMING

Periodic headlamp checks and proper aiming and adjustment are strongly recommended. Your Chevrolet Dealer is equipped and trained to properly service your headlamps.

ENGINE TUNE-UP

Every 12,000 miles have engine tune-up operations performed to maintain maximum engine performance and fuel economy.

NOTE 1: *Lubricate with water resistant EP lubricant.*

NOTE 2: *Use SAE 80 or SAE 80-90 Multi-purpose Gear Lubricant meeting requirements of U. S. Ordnance Spec. MIL-L-2105B.*

SPECIFICATIONS

SERIAL AND UNIT NUMBERS

Car—Stamped on Vehicle Identification Plate attached to left front body pillar.

Body—Stamped on plate attached to cowl panel.

Engine—Stamped on boss on block.

6-Cylinder—On right side of block to rear of distributor.

4-Cylinder—On right side of block to rear of distributor.

8-Cylinder—On right side of block at front.

DIMENSIONS

Overall Length	182.9"
Height	55.0"
Width	69.9"
Wheelbase	110.0"

CAPACITIES

Gasoline Tank			
All Models			16 gal.
Crankcase (Refill)			
4 Cylinder (with oil filter change)—1 pt. filter			4 qts.
6 and 8 Cylinder (with oil filter change—1 qt. filter			5 qts.
Differential			4 pt.
Power Steering			2.3 pts.
Cooling System			
	4 cyl.	6 cyl.	8 cyl.
	9 qts.	12 qts.	17 qts.
Thermostat	180°	180°	180°
Radiator Pressure Cap			13 lb.
Radiator Pressure Cap (Air Conditioning)			15 lb.

ENGINE SPECIFICATIONS

Engine Data	4 Cyl. Engine	6 Cylinder Engines		8 Cylinder Engines			
	153 Cu. In.	194 Cu. In.	230 Cu. In.	283 Cu. In.	327 Cu. In.	327 Cu. In.	327 Cu. In.
Carburetor	1 Barrel	1 Barrel	1 Barrel	2 Barrel	4 Barrel	4 Barrel	4 Barrel
Horsepower	90 @ 4000	120 @ 4400	155 @ 4400	195 @ 4800	250 @ 4400	300 @ 5000	350 @ 6200
Compression Ratio	8.5:1	8.5:1	8.5:1	9.25:1	10.5:1	10.5:1	11.0:1
Bore	3.88	3.563	3.875	3.875	4.00	4.00	4.00
Stroke	3.25	3.25	3.25	3.0	3.25	3.25	3.25
Firing Order	1-3-4-2	1-5-3-6-2-4		1-8-4-3-6-5-7-2			

SPARK PLUGS

The following 14mm plugs are provided for Chevy II engines.

	Normal Service (Original Equipt.)	Hotter Plug (For City-Type Operation)	Colder Plug (For Continuous Heavy Duty Oper.)
153 L-4 Engine	AC-46N	—	AC-44N
194 & 230 L-6 Engine	AC-46N	—	AC-44N
283 V-8 Engine	AC-45	AC-46	AC-44
327 V-8 Engines	AC-44	AC-45 or 46	AC-43

TIRE INFORMATION

Type	Tubeless
Size:	
4 Cylinder Sedans	6.00 x 13
6 Cylinder Sedans	6.50 x 13
8 Cylinder Sedans	6.95 x 14
All Station Wagons	7.00 x 13

FUSES AND CIRCUIT BREAKER:

A Circuit Breaker in the light control switch protects the headlamp and parking lamp circuits, thus eliminating one fuse. Where current load is too heavy, the circuit breaker rapidly opens and closes, protecting the circuit until the cause is found and eliminated.

Fuses, located in the Junction Block beneath the dash are:

Instrument and Clock Lights	3AG/AGC-	3 amp.
Tail, Stop, Dome Lights	3AG/AGC-	15 amp.
Radio (Manual and Push Button) ..	3AG/AGC-	2.5 amp.
Heater	3AG/AGC-	10 amp.
Air Conditioning (including Heater)	SAE-	20 amp.
Backup Light, Brake Signal Light ..	3AG/AGC-	10 amp.
Windshield Wiper Motor	SAE-	20 amp.

TURN SIGNAL FLASHER:

Type	Series 2-bulb
------------	---------------

BULB SPECIFICATIONS

	Candle-power	Number
Headlamp		6012
High Beam	50W	(Sealed
Low Beam	45W	Beam)
Parking Lamp and Front Directional Signal	4-32	1157
Tail, Stop and Rear Directional Signal Lamps	4-32	1157
Back-up Lamp	32	1156
Instrument Lamps	3	1816
Turn Signal Indicator Lamp	2	1895
Temperature Indicator Lamp	2	1895
Oil Pressure Indicator Lamp	2	1895
Generator Indicator Lamp	2	1895
Headlight Beam Indicator Lamp	2	1895
Glove Box Lamp	2	1895
Dome Lamp	12	211
Courtesy Lamp (Convertible)	6	631
License Plate Lamp	4	1155
Radio Dial Lamp	2	1893
Brake Indicator Lamp	2	257

MINOR TROUBLE SHOOTING GUIDE

FUEL SYSTEM AND ENGINE

ELECTRICAL SYSTEM

COOLING SYSTEM

If your car acts in the following manner:	FUEL SYSTEM AND ENGINE										ELECTRICAL SYSTEM							COOLING SYSTEM				
	Check Fuel Gauge	Flooded Carburetor	Empty Carburetor Bowl	Poor Fuel Supply to Carburetor	Idle Adjustment*	Automatic Choke*	Oil Level and Pressure	Condition of Air Cleaner	Malfunctioning Ignition Switch	Automatic Transmission Selector Lever	Check Spark	Battery and Connections	Generator and Voltage Regulator Connections	Coil and Distributor Leads	Starter Connections and Solenoid	Damp Electrical Connections	Generator Condition*	Radiator Water Level	Air Flow Through Radiator Restricted	Fan Belt Condition and Tension Adjustment	Cooling System Thermostat	Thorough Check and Tune-up Suggested*
On the following pages, see paragraph:	A	D	D	B-C-D	E	D E	L	E	F	F	K	G	G	J	H	I	G	M	N	O	P	
See information on page number:	11						10-30	35		6-8		36					10	30				31
CAR WILL NOT START:																						
Engine Will Turn Over	1	4		3							6			2		5						7
Engine Will Not Turn Over									2	1		3			4							5
CAR WILL START—BUT:																						
Only After Repeated Tries																						1
Stalls in a Few Seconds			2	1	3																	
Stalls When Hot					1	2		3														4
Idles Rough					1			2														3
Engine Overheats																		1	2	3	4	
"Oil" Indicator Light Comes On							1															
"Gen" Indicator Light Comes On												3	2				4			1		

*See Your Authorized Chevrolet Dealer

MINOR TROUBLE SHOOTING PROCEDURES

The chart on the previous page, and the information on the pages which follow, contains information designed to aid the average driver to discover, and possibly correct, conditions resulting in minor mechanical difficulties in his car. The chart, designed to point out possible solutions to several of the most common automotive malfunctions and point out a logical checking sequence, will lead step by step to the most likely causes and corrective procedures. If, after making the checks and adjustments suggested, the source of the trouble has not been found and corrected, it is strongly recommended that an Authorized Chevrolet Dealer inspect the vehicle and make whatever repairs or adjustments are necessary.

FUEL SYSTEM AND ENGINE

If the ignition switch will cause the engine to "turn over" or "crank" but the car will not start, check Steps A through D below.

NOTE: If Continual "flooding" of the carburetor is evidenced by a carburetor wet with fuel or black exhaust smoke, perform the operation suggested in paragraph D only.

(A) The first and most obvious, and one of the most frequently overlooked, items to check when you have difficulty in starting your car is the amount of fuel in the tank. Make it a habit to check the FUEL GAUGE regularly and most especially at a time when the engine will "turn over" but will not start.



Checking Fuel Flow

(B) If the fuel tank is not empty,

you may check further to see whether the fuel is reaching the carburetor. Disconnect the fuel line at the carburetor. Place a jar or cup under the open line and briefly "crank" the engine by means of the starter. If fuel spurts from the fitting, you may assume that the FUEL LINES are clear and the FUEL PUMP is operating properly. If no fuel leaves the line, either the fuel lines or fuel pump are at fault. See your Authorized Chevrolet Dealer.

(C) Before reconnecting the fuel line to the carburetor, remove the FUEL FILTER from the carburetor inlet and check its condition. If it appears to be clean, replace it and reconnect the fuel line. If the filter appears to be plugged, clean it as well as possible by scraping out the foreign material and cleaning in a solvent. Then reinstall the filter. Replace the filter with a new one as soon as possible.



Fuel Filter

(D) If the fuel seems to be reaching the carburetor properly, the problem may be a FLOODED CARBURETOR caused by a "stuck open" condition and evidenced by gasoline flowing down the outside of the carburetor; or a stuck CHOKE valve. Remove the air cleaner from the carburetor. Check that the choke valve moves freely and is not stuck. (Don't mistake normal spring tension for a stuck valve.) Tap the side of the carburetor sharply several times with a light tool such as a screwdriver handle or pliers. Replace the air cleaner and attempt to start the engine in the normal manner.

(E) If the car will start but stalls when hot or has a rough idle, you can suspect a faulty **IDLE ADJUSTMENT**, a malfunctioning **AUTOMATIC CHOKE** or an extremely dirty and blocked **AIR CLEANER ELEMENT**. Clean your air cleaner element if necessary. Idle adjustment or automatic choke service (other than that outlined in paragraph D) should be performed by your Chevrolet Dealer.

If the above Fuel System checks and the checks suggested under the Electrical System following do not correct the malfunction, it is recommended that you turn to your Authorized Chevrolet Dealer for further checks, adjustments or repairs.

ELECTRICAL SYSTEM

If, when the ignition key is turned to "Start," the engine will not turn over, you have good reason to suspect electrical trouble.

NOTE: Never remove delcotron **BAT** lead without first disconnecting battery ground cable.

(F) When there is no response at all to attempts to start the car, check the obvious—your **AUTOMATIC TRANSMISSION SELECTOR LEVER** must be in Neutral or Park position before the engine can be started. Turning the **IGNITION SWITCH** rapidly back and forth several times will sometimes correct a poor internal switch contact.

(G) The **BATTERY** may be discharged. If so, lights will be dim and the horn will have a poor tone if it will blow at all.

Usually a garage recharge will be necessary to return the battery to operation. Occasionally, however, a push start and long drive will recharge the battery.

NOTE: If the battery is determined to be dead, and for no apparent reason, have your Authorized Chevrolet Dealer check the **BATTERY**, the **GENERATOR** and the **VOLTAGE REGULATOR**. **GENERATOR** trouble should already have been indicated by the generator indicator light on the instrument panel.

POOR BATTERY CONNECTIONS may be suspected if the car has operated properly a short time before and now not even the horn will operate. Check both ends of both battery cables. If the connections are corroded, a car may sometimes be restored to operation by removing all cable ends, scraping all contacting surfaces clean with a pen knife, and reassembling. If the cables are broken, they must be replaced. The power supply should now be restored unless the battery is dead.

(H) If, however, the lights and horn work properly but the starter will still not turn over, check the **STARTER** connections. A "click" from the starter solenoid indicates that the wiring to the starter is properly installed. If the wiring seems to be clean and tightly installed, the trouble is probably in the starter itself and should be referred to your Authorized Chevrolet Dealer.

When the engine will "turn over" but will not start, the following items may be checked along with the Fuel System Checks listed previously.

(I) With a clean dry cloth wipe the ceramic portions of the spark plugs dry. In particularly damp or rainy weather dampness may be the cause of not starting, especially when the engine is cold.

(J) Check the cables at the top of the distributor and coil as well as each spark plug cable for tightness.

(K) If the car will still not start, check for spark at the spark plugs in the following manner:

Pull one of the spark plug wires off its spark plug. Insert a short piece of bare wire (such as



Distributor and Coil Cables

a bobby pin) between the rubber cup at the end of the spark plug wire and the tubular metal connector inside of it. If the spark plug wire is wet or oily, wipe it dry. Wrap a dry handkerchief or facial tissue, folded several thicknesses, around the wire at least three inches back from the end and grasp the wire at this point. Hold the bare wire about $\frac{1}{4}$ inch from the bare tip of the spark plug from which you removed the wire. When the engine is "turned over" a spark should jump across the $\frac{1}{4}$ inch space, indicating ample current supply. If no spark jumps, the difficulty is probably caused by a defective ignition part and should be corrected by your Authorized Chevrolet Dealer.



Checking Spark

COOLING SYSTEM


When the car will run but evidences serious overheating on the temperature gauge in the instrument panel, there are several items which may be checked.

(L) Engine overheating will occur when the OIL LEVEL falls dangerously low. Check the oil level as a matter of course.

(M) Low WATER LEVEL will, of course cause engine overheating. Determine the cause of the low water level and have it corrected if necessary.

(N) Check the RADIATOR CORE. Clean it if it is plugged with bugs, leaves or other foreign material.

(O) Condition of the FAN BELT is very important, not only for engine cooling but also for proper generator operation. Check the condition of the belt. Replace it if it is worn or frayed. Loosen the generator bolts and move the generator toward the engine to remove and replace the belt. Tighten the belt, whether new or old, by loosening the generator bolts, prying with a bar on the generator until the belt is tensioned properly, then retighten the generator bolts. Proper belt tension is such that, when pressed hard at a point midway between the generator and fan pulleys, the belt will deflect about $\frac{1}{2}$ inch.



Fan Belt Tension

(P) Another cause of engine overheating may be an inoperative COOLING SYSTEM THERMOSTAT. If the thermostat should fail in the closed position, it will not permit water to circulate through the system. In such an emergency the thermostat may be removed but should be replaced with a properly functioning thermostat as soon as possible.



Thermostat Installation

SERVICE LITERATURE *for* CHEVROLET CARS and TRUCKS

The following Chevrolet publications covering the operation and servicing of Chevrolet Vehicles can be purchased by filling out the order form and mailing it with check or money-order payable to Helm Inc.

1965 Shop Manuals

- ST-56 Service Manual** Price each \$4.25
Applies to Chevrolet, Chevy II and Chevelle. Includes on-the-car adjustments, Maintenance and Overhaul of minor assemblies and specifications. (e.g. windshield washers, distributor, etc. Will handle most owner's requirements.)
- ST-57 Overhaul Manual** Price each \$3.50
Applies to Chevrolet, Chevy II and Chevelle. Includes basic off-the-car overhaul of major assemblies (e.g. engine, transmission, axle, etc.)
- ST-58 Body Service Manual** Price each \$3.50
Includes all information for Chevrolet, Chevelle, Chevy II and Corvair car bodies.

Available Manuals

	FORM NO.	YEAR	PRICE EA.
CHEVROLET SHOP MANUAL	RS-34	(1949-54)	\$4.00
	RS-57	(1955)	4.00
	RS-58	(1956*)	3.00
	RS-60	(1957)	4.00
	RS-62	(1958)	4.00
	S & M-15	(1959-60*)	3.75
	S & M-32	(1961)	4.75
	ST-6	(1962*)	3.00
	ST-18	(1963**)	3.75
	ST-30	(1964 supplement)	3.50
	H-10	(1964 w/'61 for complete cover.)	6.00

	FORM NO.	YEAR	PRICE EA.
CHEVY II SHOP MANUAL	ST-7	(1962)	\$4.50
	ST-19	(1963*)	2.25
	ST-31	(1964 supplement)	2.00
	H-30	(1964 w/'62 for complete cover.)	5.00
CORVAIR & CORVAIR 95 SHOP MANUAL	S & M-21	(1960)	3.75
	S & M-34	(1961)	4.25
	ST-8	(1962*)	2.75
	ST-20	(1963**)	2.75
	ST-33	(1964 supplement)	2.50
	H-35	(1964 w/'61 for complete cover.)	5.00
CHEVELLE SHOP MANUAL	ST-59	(1965)	4.25
	ST-32	(1964)	4.75
CORVETTE SHOP MANUAL	ST-21	(1963)	4.50
	ST-34	(1964 supplement)	2.00
	H-40	(1964 w/'63 for complete cover.)	5.00
	ST-60	(1965 supplement)	2.00
	H-45	(1965 w/'63 for complete cover.)	5.00

*Previous year model manual must be ordered with this supplement to obtain complete coverage.

**1961 model manual must be ordered with supplement to obtain complete coverage.

	FORM NO.	YEAR	PRICE EA.
TRUCK SHOP MANUAL	RS-56	(1954)	\$3.75
	RS-54	(1955)	3.25
	S & M-56	(1956*)	3.00
	RS-61	(1957)	3.25
	RS-63	(1958)	3.50
	S & M-16	(1959*)	1.50
	S & M-22	(1960)	3.75
	ST-9	(1960-62*)	4.00
	ST-22	(1963)	4.75
	ST-35	(1964 supplement)	2.75
	H-15	(1964 w/'63 for complete cover.)	5.50
	ST-61	(1965 supplement)	2.75
	H-20	(1965 w/'63 for complete cover.)	5.50
CHEVY VAN SHOP MANUAL	ST-36	(1964-65 supplement)	3.00
	H-25	(1964-65 w/'63 Truck for complete coverage)	5.75

OWNER GUIDES

Chevrolet, Chevy II, Corvair, Corvair 95 and Chevelle	.30 each
Truck and Chevy Van	.40 each
Corvette	.60 each
Convertible Top booklets	.25 each

Please specify model year and vehicle when ordering.

**Previous year model manual must be ordered with this supplement to obtain complete coverage.*

AVAILABLE CHEVROLET SHOP MANUALS PRIOR TO 1949

The shop manuals listed below are out of print. The information contained in these shop manuals has been prepared on microfilm. We are able to produce a 35 mm positive film strip from this microfilm. The film can be viewed through any type of film viewer adaptable to 35 mm.

AVAILABLE FILMS

1919 Chevrolet
Car Shop Manual

1923 through 1948
Chevrolet Shop Manuals

1934 through 1952
Truck Shop Manuals

Price \$5.00 Each

(For 1953 Truck Shop Manual,
Order 1952.)

Please allow 30 days for order to be filled.

NOTE: PLEASE FILL ORDER FORM IN COMPLETELY, CUT HERE AND MAIL TO:

HELM Incorporated

Post Office Box 7706
Detroit, Michigan 48207

Please mail Check or Money Order (NO STAMPS) for the publications you have ordered on form.

NOTE: Purchasers outside Domestic U.S.A. must add 30c to each publication for mailing expense. Funds MUST be payable in U. S. Currency.

All orders will be mailed within 10 days of receipt of order. Please allow approximately 30 days for postal service.

QUANTITY	FORM NO.	YEAR	PRICE EA.	TOTAL
_____	_____	_____	_____	_____
_____	_____	_____	_____	_____
_____	_____	_____	_____	_____
_____	_____	_____	_____	_____
_____	_____	_____	_____	_____
_____	_____	_____	_____	_____
Remarks _____				

Michigan Purchasers —
add
4% Sales Tax

Total Order _____
(of both columns)
Michigan Sales Tax _____

Grand Total _____

Prices subject to change after July 1, 1965

PLEASE COMPLETE SHIPPING LABEL BELOW

SIGNATURE OF PURCHASER _____

STREET ADDRESS _____

CITY, POSTAL ZONE, STATE
IMPORTANT: This is your shipping label — Please print clearly

From...

HELM Inc. Chevrolet Manual Distribution Department

POST OFFICE BOX 7706

• DETROIT, MICHIGAN 48207

For

(NAME) _____

(STREET ADDRESS) _____

(CITY, ZONE, STATE) _____

RETURN REQUESTED _____

