

**HUDSON
SUPER
SIX**

1933

**OWNER'S MANUAL
OF INFORMATION**

TO THE OWNER of this

HUDSON SUPER SIX MOTOR CAR

A great deal of money, time and care has been devoted to the proper designing, manufacturing and preparation of this car for delivery into your hands.

We share your pride in its character and appearance, and our sincere hope is that you derive from its operation the full enjoyment and utility to which you looked forward in purchasing it.

For these reasons, may we take the liberty of suggesting that a fine mechanism such as this new car of yours will always respond with its best to considerate treatment and care?

It will repay you well for the slight outlay in attention and cost required to give it regular and proper lubrication, inspection at stated intervals, and such adjustments as may be indicated from time to time. This is to bespeak for your car and your own pocket no more nor less than *the ounce of prevention which is worth so much more than the pound of cure.*

Hudson and Essex Distributors and Dealers in your community, and practically everywhere you may drive, are prepared with equipment facilities and experienced personnel to give your car uniform, proper and complete attention in these respects at moderate prices for the materials supplied and services rendered. We commend to you their expert and friendly interest in your car.

As to this manual itself, its chief purpose is to acquaint you with the means of taking the best care of your car, so that you may derive from it the full measure of operating quality and long economical life built into it at the factory. Will you coöperate to the extent of reading this manual and keeping it in one of the side pockets of your car for ready reference as needed?

HUDSON MOTOR CAR COMPANY

Detroit, Michigan

INDEX

General

	Page
BREAKING-IN INSTRUCTIONS.....	11
CARE OF THE FINISH.....	30
LICENSE DATA AND TECHNICAL INFORMATION.....	5
OPERATION.....	8
STARTING THE ENGINE.....	10
WARRANTY.....	4

Lubrication

BRAKE CROSS SHAFT.....	20
CHASSIS LUBRICATION CHART.....	12
CLUTCH.....	15
DISTRIBUTOR.....	14
DOOR DOVETAILS.....	20
DOOR LOCKS.....	20
ENGINE.....	13
FRONT WHEEL BEARINGS.....	19
GENERATOR.....	14
HOOD LOCKS.....	20
REAR AXLE.....	18
REAR WHEEL BEARINGS.....	19
STARTING MOTOR.....	14
STEERING GEAR.....	20
THROTTLE CONTROL RODS AND LEVERS.....	20
TRANSMISSION.....	15
UNIVERSAL JOINTS.....	18

Adjustment

BATTERY.....	24
BRAKES.....	27
CLUTCH PEDAL.....	23
FAN AND GENERATOR BELT.....	22
FRONT WHEEL ALIGNMENT.....	27
FRONT WHEEL BEARINGS.....	25
HEADLAMPS.....	30
IGNITION TIMING.....	21
RADIATOR.....	29
REAR WHEEL BEARINGS.....	25
SHOCK ABSORBERS.....	27
SPARK PLUGS.....	29
SPRING MOUNTINGS.....	28
STEERING GEAR.....	24
TAPPETS.....	23
TIRES.....	26
WHEELS—REMOVAL AND INSTALLATION.....	26
WIRING DIAGRAM.....	16-17

Warranty

"We warrant each new passenger automobile manufactured by us to be free from defects in material and workmanship under normal use and service, our obligation under this warranty being limited to making good at our factory any part or parts thereof, including all equipment or trade accessories (except tires) supplied by the Car Manufacturer, which shall, within ninety (90) days after making delivery of such vehicle to the original purchaser or before such vehicle has been driven 4000 miles, whichever event shall first occur, be returned to us with transportation charges prepaid, and which our examination shall disclose to our satisfaction to have been thus defective, this warranty being expressly in lieu of all other warranties expressed or implied and of all other obligations or liabilities on our part, and we neither assume nor authorize any other person to assume for us any liability in connection with the sale of our vehicles.

"This warranty shall not apply to any vehicle which shall have been repaired or altered by other than an authorized Hudson and Essex Distributor or Dealer in any way so as, in the judgment of the Manufacturer, to affect its stability or reliability nor which has been subject to misuse, negligence or accident."

HUDSON MOTOR CAR COMPANY
Detroit, Michigan, U. S. A.

License Data

CAR SERIAL NUMBER (On plate on dash under hood)—1300501 and up
 ENGINE SERIAL NUMBER—Stamped on left side of cylinder block opposite cylinder No. 3—2001 and up
 CYLINDER BORE— $2\frac{15}{16}$ "
 PISTON STROKE— $4\frac{3}{4}$ "
 NUMBER OF CYLINDERS—6
 N. A. C. C. HORSEPOWER RATING—20.7
 PISTON DISPLACEMENT—193

Body Types

COACH	2-PASSENGER COUPE
STANDARD SEDAN	CONVERTIBLE COUPE
RUMBLE COUPE	PHAETON

Technical Information

Engine

TYPE—6 cylinders	CAMSHAFT DRIVE—Helical Gears
ACTUAL DEVELOPED H. P.—73 at 3200 R. P. M.	CONNECTING ROD LOWER BEARING CLEARANCE — .001"-.0015"; Side Clearance, .006"-.010"
COMPRESSION RATIO—6.2 to 1	PISTON MATERIAL—Silicon Aluminum Alloy
FIRING ORDER—1-5-3-6-2-4	PISTON TYPE—T Slot Cam Ground
NUMBER MAIN BEARINGS—3	PISTON WEIGHT— $9\frac{1}{4}$ ounces
TYPE OF CRANKSHAFT—Fully Compensated; Statically and Dynamically Balanced	SKIRT CLEARANCE—Top, .0015"-.002"
MAIN BEARING CLEARANCE—.001"-.0015"	SKIRT CLEARANCE—Bottom, .0005"-.001"
MAIN BEARING END PLAY—.006"-.012"	NUMBER OF PISTON RINGS—Compression, 2; Oil Control, 2
VALVE MATERIAL—Silicon Chrome Alloy Steel	PISTON RING GAP—.009"-.011"
VALVE HEAD DIAMETER—Intake, $1\frac{3}{8}$ "; Exhaust, $1\frac{3}{8}$ "	LUBRICATION—Duoflo Automatic System
VALVE TAPPET CLEARANCE—Intake, .003"-.005"; Exhaust, .005"-.007". Measure with engine hot	OIL PUMP TYPE—Oscillating Plunger

Cooling System

TYPE—Pump Circulation COOLING SYSTEM CAPACITY—3 gals.
 RADIATOR TYPE—Copper Ribbon FAN BELT—"V" Type
 Cellular

Fuel System

CARBURETOR—1 1/4" Marvel Air FUEL FEED—Pump
 Valve Type GASOLINE TANK CAPACITY—16 gals.
 AIR CLEANER—Flame Arrester Silencer Type

Starting and Ignition

MAKE—Auto-Lite SPARK PLUG GAP—.022"
 SPARK CONTROL—Full Automatic GENERATOR REGULATION—Third
 TIMING—Dead Center Brush
 FIRING ORDER—1-5-3-6-2-4 GENERATOR NORMAL CHARGING RATE
 DISTRIBUTOR POINT GAP—.020" —6 volts, 14 amps.; 7 volts, 16
 SPARK PLUG SIZE—14 mm.-Metric amps.; 8 volts, 18 amps.

Lamp Bulb Specifications

	C.P.	Base	Voltage		C.P.	Base	Voltage
HEAD	21-21	D.C.	6-8	DASH	3	S.C.	6-8
SIDE	3	S.C.	6-8	STOP & TAIL	2-21	D.C.	6-8
TELLTALE	3	D.C.	6-8	DOME	15	S.C.	6-8


LIGHTING CIRCUIT FUSE SIZE—30 amps.

Clutch

TYPE—Oil Cushioned Single Plate CLUTCH PEDAL CLEARANCE AT FLOOR
 with Modulator Hub BOARD—1 1/2"

Transmission

FEATURES—Full Range Selective, Silent Second, Synchro-Mesh with Free Wheeling with Automatic Retraction Reverse SPEEDS—3 forward, 1 reverse



Operation

The operation of the Hudson Super Six follows standard practice in many respects; however, even those accustomed to Hudson products may refresh their memories on some of the details by reading the following paragraphs:

The clutch is disengaged in the conventional manner by depressing the left foot pedal to release the engine drive from the transmission. When the button on the left of the steering column bracket is down the automatic clutch control becomes operative. The clutch is then disengaged simply by removing the foot from the accelerator pedal.

The transmission operation conforms to the standard shift. The clutch must be disengaged, by the use of the pedal on the automatic control, to shift gears except when the car is in motion and "free wheeling."

Free wheeling is obtained by pressing the button on top of the shifting lever knob and pulling the knob up until the button comes out flush with the top of the knob. To revert from "free wheeling" press the button and push down on the knob until the button comes out flush.

It is possible to change to "free wheeling" at any time. To change from "free wheeling" to conventional drive when the engine is driving the car simply depress the button and knob. If the knob does not come out flush, release the accelerator pedal slightly while still pushing down on the knob.

If the car is in motion and the engine is running at idling speed, increase the speed of the engine so that it drives the car, or depress the clutch before changing from "free wheeling" to conventional drive.

The brakes are operated either by depressing the right foot pedal or pulling backward on the hand lever located on the driver's left just ahead of the front door.

The engine speed can be controlled either by the foot accelerator or the throttle knob, which is located on the instrument panel above the ignition lock.

The light control knob is located directly to the left of the ignition lock. Pulling the knob out to the first position gives side lights and head lights in the second position. The head light control is located on the toe board to the left of the clutch pedal. If the head lights are on "bright" they are "dimmed" by pressing this foot control. A second depression of this control returns the lights to "bright."

The service lamp is located on the instrument panel above the instrument group. When the lamp is pulled out it automatically lights.

The starter is controlled by the ignition lock. When the ignition key is turned to the right, the ignition is turned "on" and the starter is brought into operation. Should the engine stop while the key is turned to the right, the automatic starter will immediately engage and re-start the engine. If the car is in gear when the engine stalls, the clutch pedal should be depressed until the engine starts.

If it is desired to turn the engine by the starter without starting the engine, push the plunger which extends out of the rear face of the automatic starter relay box (under hood at left of engine). Hold the plunger down firmly and release quickly by sliding the finger off sidewise to prevent the plunger sticking. Should the plunger stick so that the engine continues to turn, push it in again and release quickly.

The carburetor choke control knob is located to the right of the ignition lock. (See "Starting the Engine" for use of choke.)

The oil pressure signal is the red jewel located to the left of the center of the instrument group. When the ignition switch is turned "on" this signal will be lighted and should stop glowing when the engine is running. If it remains lighted or flashes while the engine is running above idling speed, the engine should be stopped and the oil level in the reservoir checked. If necessary, check the oil lines. Do not run the engine until the trouble is corrected.

The generator signal is the red jewel located to the right of the center of the instrument group. When the ignition switch is turned "on" this signal will be lighted and should stop glowing when the engine reaches a speed slightly above normal idling. If the signal flashes when the car is being driven above twenty miles per hour, it indicates that the battery is not being charged. Your electrical system should be checked by your Hudson dealer.

The "gasoline or oil" gauge, located in the lower right corner of the instrument group, indicates the quantity of gasoline in the tank when the ignition switch is turned "on." By pushing upward on the button located below the ignition switch and extending from the bottom of the instrument panel, the hand of this gauge indicates the quantity of oil in the reservoir of the engine.

The engine temperature indicator is located in the lower left corner of the instrument group.

Starting the Engine

The proper procedure in starting the engine is as follows: See that the throttle control knob is in. Do not open throttle with the accelerator until the engine starts. Pull the choke knob out as far as possible. Insert the ignition key in the lock and turn clockwise. When the engine "fires" push the choke in until it runs evenly. If the engine is cold, the choke can only be pushed in about three-eighths of an inch. Never leave the choke out farther than necessary to keep the engine running smoothly. It should be pushed in to the limit of its travel as soon as possible after starting the engine.

Breaking-in Instructions

Keep Radiator Full

Heat is a major consideration in a new engine. Do not allow the engine to overheat. Although the heat indicator on the instrument panel shows the general temperature of the engine, it will not show a sudden rise in temperature of an individual part.

The pressure imposed on parts such as bearings and pistons due to rapid acceleration or hard pulling will cause them to overheat if the car has not been driven sufficiently to break them in. Avoid fast acceleration and hard pulling while breaking in.

High speed also develops higher operating temperatures and to avoid damage the car speed should be kept within the following recommendations:

0-250 MILES

Do not exceed 40 miles per hour in high gear or 20 miles per hour in second. Do not accelerate rapidly. Use second gear on steep grades. Keep motor temperature within "driving range" on dash heat indicator.

250-500 MILES

Do not exceed 50 miles per hour in high gear or 25 miles per hour in second.

500-1000 MILES

During this period the speed should not exceed 60 miles per hour.


IMPORTANT

Do not UNDER ANY CONSIDERATION attempt to maintain a high rate of speed unless the crankcase is full of good oil and until the engine is thoroughly warmed up. Cold oil is not able to flow freely into the small clearances between working parts so that damage may occur if sufficient time is not allowed for warming up before attaining high speeds.

Lubrication

Engine

Use High-Grade Oil—Medium Heavy Body—S. A. E. 30



Select an oil for winter driving that will flow at the lowest temperature encountered. Consult your dealer if you are in doubt as to what oil to use.

When the ignition switch is turned "on" the red jewel to the left of the center of the instrument board should flash red. If it does not, the bulb is either burned out, the circuit to the oil relief valve broken or the oil relief plunger sticking.

As soon as the engine is running, the light should go out. A flash of the red jewel while the engine is running above idling speed indicates interruption of the oil supply. The engine

should be stopped immediately and the lubrication system inspected.


The amount of oil in the reservoir is shown on the gauge on the instrument panel when the ignition electrolock is turned "on" and the button under the instrument panel below the gauge is pressed up.

A bayonet gauge is also provided at the oil filler on the left side of the engine. See illustration.

The Hudson Duoflo oiling system provides not only purification from dilution but also double screening and cooling of the oil. The oil is therefore maintained in good condition for a longer time than in other lubricating systems. Oil should be added as necessary to maintain the quantity in the reservoir. The reservoir should be drained and refilled with six (6) quarts of oil at least every 2500 miles.

It is, however, recommended to drain the initial supply of oil after the first 500 miles of driving. To drain the reservoir remove the plug from the rear of the oil reservoir. Be sure the drain plug is tightened securely when replaced.

Clutch




Use 1/6 Pint of Light Motor Oil and 1/6 Pint of Kerosene

The clutch lubricant is sealed into the clutch and supplies the driving surfaces as well as the throwout bearing with oil.

The life of the lubricant is largely dependent on the usage of the clutch. Harsh clutch action indicates the need of fresh oil and the clutch should be promptly inspected by your Hudson dealer if this condition develops. In any event, the oil should be changed at least every 15,000 miles.

To drain the clutch, crank the engine by hand until the oil filler plug "A" on the front side of the flywheel is visible through the timing inspection hole. Remove the plug and turn engine slowly to allow lubricant to drain. Bring plug hole back to opening and insert new lubricant. Replace the drain plug securely.

Transmission




The lubricant in the transmission and free wheeling units should be maintained to the level of the filler plugs "A" and "B."


The plugs "C" and "D" should be removed every 5000 miles and the lubricant drained out. Replace the plugs and fill through plug "B" with one quart of kerosene. Run engine with transmission in neutral and clutch engaged for one minute. Drain kerosene, replace drain plugs and fill through "B" with three pints of S. A. E. No. F.W. 110 gear oil (in winter use S. A. E. No. F.W. 80),

allowing the oil to drain into the main transmission housing. If the full three pints cannot be put in at "B," add the balance at "A."

It is essential that good oil of the proper body be used to insure proper protection against wear and permit proper gear changing. Buying according to the S. A. E. specifications (this is shown on most oil containers) will insure you of obtaining a satisfactory lubricant.




WIRING



DIAGRAM


Adjustment

Engine Tuning



Do not attempt to adjust the carburetor alone. Perform all of the following operations in the order given:

1. Clean spark plugs and adjust gaps to .022".
2. Clean distributor breaker points and adjust to .020" maximum opening as described under Ignition Timing.
3. Check battery and ignition wiring, being sure all distributor wires are pressed down in their sockets.
4. Set ignition timing as described under Ignition Timing.
5. Adjust intake valve tappet clearance to .006" and exhaust tappet clearance to .008".
6. Turn carburetor idling screw "A" until the end is flush with the end of the ratchet spring.
7. Start engine.
8. Set carburetor throttle stop screw "D" so that engine idles at a speed equal to a car speed of 7 m.p.h. in high gear.




9. Adjust carburetor idling screw "A" for smooth engine idling. The final adjustment should be $\frac{1}{2}$ turn of the screw from the flush position.

If the above operations, properly performed, do not give normal engine performance, the car should be taken to a Hudson dealer for mechanical inspection.

Ignition Timing

Remove distributor cap and inspect points. High points can be removed by placing a breaker point file between points and letting them close against file under their normal spring pres-



Ignition Timing Continued

sure. Move file straight up and down, dressing both points at the same time.

Crank engine until the breaker arm fiber block is on the highest point of the cam, giving the points their maximum opening. If necessary to adjust, loosen lock nut "D" and turn screw "E" until the gap is .020". Tighten lock nut.


Remove the spark plug from number one cylinder. Crank the engine slowly by hand until air is forced out through the spark plug hole. Continue turning the engine slowly until

the D. C. 1 and 6 mark is exactly in line with the pointer as shown at "A" (page 21).

Loosen clamp screw "B" and turn distributor clockwise to the full limit permitted by the slot in the clamping plate "C."

Turn the distributor counterclockwise until the points have just begun to open. Tighten lock screw "B."


When the engine is in this position the rotor arm "F" will point directly to the sector in the distributor cap to which number one spark plug cable is connected. Following around the cap clockwise from this point the spark plug wires should be in the following order: 1-5-3-6-2-4.



Fan and Generator Belt

The fan and generator drive belt must be kept at sufficient tension to prevent slippage on the pulleys. Do not adjust too tightly or rapid wear on fan and generator bearings will result. To adjust belt tension, loosen nut "A" and swing generator away from engine to tighten. Then lock adjustment by thoroughly tightening nut "A."

Tappets



Before adjusting tappets see that the tappet clamp cap screw "C" is tight. Adjust tappet by loosening lock nut "B" and turning adjusting screw "A." Lock adjustment by tightening lock nut "B" while holding screw "A."


Measure clearance between adjusting screw and end of valve stem with a feeler gauge as shown at "D" in the illustration. This measurement should be made while the engine is at its normal operating temperature.

Adjust exhaust valve tappets to .006" clearance and intake tappets to .004" clearance.

Counting from the front the exhaust tappets are 1-3-6-7-10-12 and the intake tappets are 2-4-5-8-9-11.

Always adjust tappets after grinding valves.

Clutch Pedal




A clearance of $1\frac{1}{2}$ " must be maintained between the clutch pedal shank and the toe board, as shown in the illustration at "A."

This adjustment should be made accurately, as too much clearance will reduce the pedal movement and may prevent complete clutch disengagement, causing hard shifting. Too little clearance may, after slight wear of the clutch disc facing, permit the clutch pedal to rest against the toe board and hold the clutch in partial disengagement. This will cause slippage and rapid wear.

To adjust, remove the clevis pin "B" and loosen the lock nut "C."

Turn the yoke on the link to obtain proper length. Lengthening the link increases the clearance between the clutch pedal shank and the toe board, while shortening the link reduces it.

Steering Gear



The bearings on the steering gear worm shaft are preloaded by the pressure of a spring located between the outer race of the upper bearing and cover plate. This spring pressure prevents development of end play in the worm, so that no adjustment is necessary to take care of normal wear.

To remove side play in cross shaft: The adjustment for cross shaft "F" is on the opposite end to that shown in the illustration. Loosen the lock nut and with a screwdriver turn the adjusting screw down as tightly as possible, then back up slightly. Tighten lock nut.

To remove play in mesh of worm and cross shaft sector: Locate wheels in


straight-ahead position, disconnect drag link from steering arm and shake arm to determine the amount of play. Loosen four stud nuts "D" ($\frac{1}{4}$ turn only). Turn eccentric sleeve "C" to right or clockwise direction only in gradual stages, noting result by shaking steering arm at each step and using care at last stage to turn sleeve just sufficiently to remove play and no further. Securely tighten cover stud nuts "D."

To change position of steering wheel to suit requirements of driver: It is necessary to loosen frame bracket stud nuts "E," as well as cowl bracket nut under cowl, then set steering wheel at desired position.

Keep the steering column to dash clamp bolt, the cross shaft nut "G" and the frame stud nuts "E" tight.

Battery


Periodically disconnect terminal "A" from the battery. Clean thoroughly, coat with vaseline, replace and tighten securely.



Battery must be kept securely fastened in tray. Tighten at "B."

Inspect battery liquid at least every two weeks in warm weather (required less frequently in cooler weather) and add distilled water at openings "C" to cover plates if necessary.


Front Wheel Bearings



The adjustment of the front wheel bearings is important, as it affects braking and steering, as well as the free running of the car.

To adjust the front wheel bearings, jack up the front wheel, remove the inner and outer hub caps and withdraw cotter key holding nut "B." Tighten nut "B" until a slight drag is felt when turning the wheel slowly by hand. Loosen the nut just sufficiently to permit the wheel to turn freely, insert cotter key and replace hub caps.

Rear Wheel Bearings



To adjust rear wheel bearings, jack up rear of car and remove both rear wheels. (See page 26 for method of removing wheels.) Remove wheel hubs as described under "Rear Wheel Bearings." (See page 19.)


Unscrew four screws holding grease deflector "A" and remove deflector. Remove four screws from bearing cap "B" and remove cap. By reducing the number of shims under the cap, the end play of the axle shaft is de-

creased, and the installation of additional shims increases the end play.

Total end play between the axle shafts should be from .004" to .010", which amount is perceptible when pulling the axle shaft in and out.

Approximately the same thickness of shims should be used under each bearing cap so that the brake drums will be evenly spaced from the brake dust shields.

Removal and Installation of Wheels



To remove either the demountable wood or wire wheels, place a screwdriver behind the hub cap and pry off. Loosen the five cap screws "A" with the socket wrench provided in the tool kit. Remove the cap screw "A" which is at the lowest position on the wheel and insert the handle of the wrench through the screw hole in the wheel into the hub. While holding the wheel in position with the wrench, remove the other cap screws "A" and lift off the wheel.

When reinstalling the wheel, jack up the car so that there is just sufficient clearance for the wheel to slide onto the hub. Place the handle of the wrench

through the lower cap screw hole in the wheel and the drum. Lift up on the wrench so that the wheel will clear the ground and push the wheel in place. Align the screw holes by moving the wrench back and forth. While holding the wheel in place with the wrench, start at least two of the cap screws. Remove the wrench and start the remainder of the screws.

Tighten every other cap screw until all are down just enough to hold the wheel in place to be sure it is square on the hub. Tighten every other cap screw, continuing around until all screws are securely tightened.


Tires

Check tires once a week and keep inflated to a minimum pressure of 32 pounds. Be sure front tire pressures are equalized.

To remove the tires from the wheels, let all air out of the tube. Push valve stem up into tire. Starting at the valve stem, press the beads of the tire together and into the base of the rim for about one foot in each direction. Insert an iron under both beads directly opposite the valve and force the tire over the rim. The tire can then be lifted off.


To install a tire, inflate the tube until it is barely round and place it in the casing with the valve stem in line with the red dot on the side wall of the casing to preserve the tire balance. Press the beads of the tire together at the valve stem and place tire on wheel so that the beads go to the bottom of the rim well and the valve stem enters the hole in the rim. Working both ways from the valve stem, press the beads together and down into the rim well until the portion of the tire opposite the valve can be forced over the rim. Raise tire up and allow beads to spread until the tire is centered on the rim. Inflate tube to five pounds pressure and work tire back and forth to insure proper seating of tire on rim. Inflate to proper operating pressure.

Spring Mountings




Chassis noise, erratic spring action and wandering of the car on the road can often be attributed to spring mountings.

Adjust the spring shackles to remove end play of spring on shackle bolt by loosening the locking nut "A" and turning the bolt "B" until tight, then turn back one-sixth turn and tighten nut "A."




This operation should be performed every 5000 miles on both upper and lower shackle bolts at the rear of both the front and rear springs and on the anchor bolts (not illustrated), holding the front ends of front and rear springs to the frame brackets.



The spring clip nuts (front and rear) shown in the illustration should be tightened every 5000 miles.

When making the above adjustments the body hold-down bolts should also be tightened. There are eight of these, four on each side, located just outside the frame side members and under the body sills. Draw the nuts tight after the first 1500 miles and every 5000 miles thereafter.

Radiator



Drain, flush out and refill frequently.

Filler is located under the hood to eliminate possibility of anti-freeze ruining the finish on the hood.

About every four months a solution consisting of one pound of washing soda to four gallons of water should be poured into the radiator and allowed to slowly circulate through the system by running the engine at idling speed. Leave drain cock open and thoroughly flush out after cleaning.

See that hose is in good condition and all hose clamps are tight.

Do not allow mud, etc., to clog air passages through radiator.

Repair dents and leaks when they occur.

Add an anti-freeze solution to the radiator in cold weather.

Drain enough water from the radiator so that after the anti-freeze has been added there will still be room for a slight expansion of the liquid without its running over the overflow pipe.

Add Anti-Freeze as Follows:

For	Ethylene Glycol	or Alcohol	or Radiator Glycerine
32° to 10° above 0°	5½ qts.	6⅔ qts.	9¼ qts.
10° to 0°	7 qts.	8⅔ qts.	11½ qts.
0° to 10° below 0°	8⅓ qts.	10 qts.	13⅔ qts.
10° to 20° below 0°	9½ qts.	11¼ qts.	15⅓ qts.

Spark Plugs

When setting the gap of the spark plugs, make all adjustments by moving the side wire. Do not bend center wire as this may break the porcelain.

To clean the carbon from the porcelain, fill the lower part of the plug with alcohol, liquid metal polish or equal parts of ammonia and water, and allow it to stand for a few seconds. Take a piece of wire covered with one thickness of cloth and rub the carbon from the insulator, wiping thoroughly dry before replacing the plug in the engine.

Spark plugs should be changed every 10,000 miles for better engine performance. New spark plugs give quicker starting, increased power, smooth running and a saving in gasoline.

